






.installationGuide* string lock




Ensure proper depth of holes
and adjust length of mounting
screws if required



Ensure proper angle of string
over nut or zero fret



If mounted close to the edge, or
if screws are kept at full length,
the neck may be drilled through



If mounted too close, or too low,
strings may be difficult to insert